Cable and Wireless Fitting Guide

Beltone Solus Max™							
	20310800 (Noahlink Wireless)	**21983900** CONN SYS,CS44,L,BLUE-RED,GRY **21984000** CONN SYS,CS44,L,RED-RED,GRY **21992200** (CONN SYS, CS63, FLEX, CLIP, RED) CS63) **19181700** (STRIP, FLEX, CS63)	**21985100** CONN SYS,CS63,MINI DIN,BLU **21985200** CONN SYS,CS63,MINI DIN,RED **19181700** (STRIP, FLEX, CS63)	**21983900** CONN SYS,CS44,L,BLUE-RED,GRY **21984000** CONN SYS,CS44,L,RED-RED,GRY **19533900** (ADAPTER, FLEX, 3 PIN, CS53)	**21983900** CONN SYS,CS44,L,BLUE-RED,GRY **21984000** CONN SYS,CS44,L,RED-RED,GRY **19902500** (ADAPTOR 2)	**18523700** (IIC 10A PILL CABLE, LEFT) **18523800** (IIC 10A PILL CABLE, RIGHT)	**21983900** CONN SYS,CS44,L,BLUE-RED,GRY **21984000** CONN SYS,CS44,L,RED-RED,GRY **19215000** (KIT, SUPER POWER, LO90)
Beltone Achieve™							
RIE WL - IMPx64	●						
RIE WL - IMPx63 Rechargeable	●						
RIE WL - IMPx63 Non Rechargeable	●						
Beltone Imagine™							
RIE WL - IMGx64	●						
RIE WL - IMGx63 Rechargeable	●						
RIE WL - IMGx63 Non Rechargeable	●						
BTE WL - IMGx76, IMGx86	●						
Custom WL Rechargeable	●						
Custom non-WL		●	●	●			
Beltone Amaze™							
RIE WL - AMZx64	●				●		
RIE WL - AMZx63 Rechargeable	●						
RIE WL - AMZx63 Non Rechargeable	●	●	●	●			
BTE WL - AMZx76, AMZx86	●				●		
BTE WL - AMZx66	●	●	●	●			
Custom WL	●	●	●	●			
Beltone Rely™							
RIE WL - REx64	●				●		
RIE WL - REx63 Rechargeable	●						
RIE WL - REx63 Non Rechargeable	●	●	●	●			
BTE WL - REx76, REx86	●				●		
BTE WL - REx95	●						●
BTE WL - REx66	●	●	●	●			
Custom WL	●	●	●	●			
Beltone Trust™							
RIE WL - TSTx64	●				●		
RIE WL - TSTx63	●	●	●	●			
BTE WL -TSTx76, TSTx86	●				●		
BTE WL - TSTx66	●	●	●	●			
Custom WL	●	●	●	●			
Custom non-WL		●	●	●			
Custom IIC						●	
Beltone Boost Ultra™							
BTE WL - BBUx95	●						●
BTE WL - BBUx86	●				●		

M201599GB-23.01-Rev.B

Beltone™